



Installation Guide

All Models: Before starting any electrical work always disconnect the negative battery terminal in the trunk. Failure to do so may result in ECU damage.

Never disconnect the ECU Power Kit, harness, or any wires while the battery is connected. Before starting scroll through the install guide and review the appropriate directions.

1. Open the hood

2. Lock and close doors and trunk, and wait 10~15 minutes for the ECU to go to sleep. If you have comfort access place keys inside the house to avoid waking up the ECU. Alternatively you may disconnect the negative battery terminal. Do not open the doors or unlock the car while the ECU connectors or ECU Power Kit are unplugged.

(Below is Triton picture but instructions are mostly the same for all makes and vehicles)



- 1. Battery**
- 2. Common rail**
- 3. Map (For Gauge Use only)**



1. Find the common rail connector



2. Install common rail connector to our ECU connector



3. Connect red wire to battery